

Cast Stone Product Installation

INSTALLATION:

An experienced mason should be used for precast stone installation. Pieces are normally dry-set with plastic setting buttons allowing for ¼" joints. Depending upon your situation, the installer may pin, strap or use latex modified adhesives to adhere the pieces to the substrate. After all stones have been installed, mortar or grout is tucked into all open joints. Care must be used to assure that mortar does not dry on the mantel face. Sponge with clean water as grouting proceeds. If field cutting is necessary, cast stone can be easily cut with a diamond blade. After installation is complete, the mantle can be cleaned with a mild soap and water.

MAINTENANCE:

Periodic cleaning of your cast stone, if necessary, should be done with a good quality stone cleaner and a natural bristle brush. Do not use wire brushes of any type.

SEALERS:

Our products are not pre-sealed. We recommend sealer underproduct installation, such as 511 from Home Depot or Tile Supply.